






 RA0500/3
Lock bushing for diff-srew
Differential-Schraubensicherung



 RA1501/1
Diff-outdrive right
Differential-Ausgang rechts



 RA1501/2
Diff-outdrive left
Differential-Ausgang links


 RA0274 X2
Diff-washer
Differential-Scheibe


  RA0279 X2
Diff ball bearing 8x5x3mm
Differential-Kugellager 8x5x3mm


  RA0277/1
C-clip for Differential
Sicherungsring für Differential

  RA0277/3
Differential trust bearing
Differential-Drucklager


  RA0277/4 X4
Cup spring
Tellerfeder

 RA0275 X10
Diff-ball, ceramic
Keramik Differential-Kugel

 RA0277/2
M3x20mm socket head screw
M3x20mm Zylinderkopfschraube



*Note direction of cup springs
*Einbaurichtung der Tellerfedern beachten



 (Not include)
*Diff grease (white)
*Diff Fett (weiß)

